DIRECT. LAMP
16-ORANGE GEN. TR.
16-ORANGE GEN. TR.
LAMP
DIRECT. LAMP
16-BLK.
16-BLACK
STOP LAMP TELL-TALE
16-RED BLACK TR.
FRONT DIRECT. LAMP RELAY (3-LAMPS)
DIRECT. LAMP TELL-TALE
16-NAT. GRN. & RED CR. TR.
71
16-ORANGE NAT. TR.
16-ORANGE NAT. TR.
16-ORANGE
16-ORANGE
16-NATURAL
16-NATURAL-BLK. & RED CR. TR.
STOP LAMP RELAY
DIRECTIONAL SWITCH (NEUTRAL POSITION)
16-RED BLK. TR.
31
16-RED BLK. TR.
16-RED NAT. TR.
16-BLK.-ORANGE TR.
16-ORANGE
14-GRN. NAT. CR. TR.
11
14-GRN. NAT. CR. TR.
11
14-GRN. NAT. CR. TR.
16-RED GRN. TR.
16-BLK. BLUE TR.
81
16-BLK.-RED CR. TR.
32
ELECTRONIC FLASHER
21 CIRCUIT BREAKER
14-GRN.-RED CR. TR.
16-RED
16-BLK.-WHITE STRIPE
HOT BUS
STOP LAMP SWITCH
14-BLK.
41
14-GRN.-2-BLK. 11-TR.
14-BLK.
51
14-BLK.-2-RED-11-TR.
4 CIRCUIT BREAKER
HOT BUS
EMERGENCY FLASHER SW.
16-RED GRN. TR.
16-BLK. ORANGE TR.
16-RED NAT. TR.
16-BLK. BLUE TR.
64
16-ORANGE GRN. TR.
16-NAT.-BLK. CR. TR.
21
19
16-NAT.-RED CR. TR.
1
16-NATURAL
61
16-ORANGE
STOP LAMP RESISTOR
16-BLK.-RED CR. TR.
16-NATURAL
16-NATURAL
16-NAT. BLK. & RED CR. TR.
16-NAT. RED TR.
16-NAT. RED TR.
REAR DIRECT. LAMP RELAY (2-LAMP)
16-ORANGE BLK. TR.
51
16-ORANGE BLK. TR.
16-VIOL.-BLK. CR. TR.
21
16-BLK.
16-BLK.
L.S. REAR STOP & DIRECT. LAMP
L.S. FRONT DIRECT. LAMP
PLAIN
RIBBED
L.S. SIDE DIRECT. LAMP
DIRECTIONAL SWITCH OPERATION
LEFT TURN POSITION
RIGHT TURN POSITION

LEGEND

| SYMBOL | JUNCTION |
|---|---|
| ▭ | DRIVERS CONTROL PANEL |
| □ | ELECTRONIC COMPARTMENT JUNCTION |
| ☑ | ENGINE CLOSURE DOOR |
| ○ | DIRECTIONAL AMPHENOL PLUG |
| △ | EMERGENCY FLASHER |

T-1429

op and Directional Lamp Wiring Diagram (Greyhound) — MD-95120